


MARUYASU Corporation

3-21-5 RYOGOKU SUMIDAKU
TOKYO 130 0026 JAPAN
www.maruyasu-fil.co.jp

Date: 05/03/2025

TECHNICAL DETAILS

| | | | |
|--------------------|---|-----------|---------|
| YARN DESCRIPTION : | SPUGNA MOLE | | |
| COMPOSITION: | WOOL86% POLYESTER14% | | |
| COUNT: | Nm.1/1.9 | KNITTING: | 3G-1PLY |
| TYPE OF DYEING: | Hank about 200g per hank | 1CONE: | 0.5KG |
| STOCK SERVICE: | YES Minimum=1kg L/T:dyeing 3-4weeks+chenille 2-5weeks(depends on the qty) | | |
| OWN COLOR: | YES Minimum=4kg L/T:dyeing=3-4weeks+chenille 2-5weeks(depends on the qty) ※NOTE: If the RW is out of stock: spinning 8-10weeks+dyeing 3-4weeks+chenille 2-5weeks | | |
| FINISHING: | · Pre-soaking 15-20min (Water temp. 35°C)* · Washing 5 min with some softener (Water temp. 35°C) · Dehydrator 1min · Drying 3min · Press with a lot of steam. ※It is necessary to make specific trials in your own knits before starting production since the final result always depends on your equipment and the tension and stitch you choose. | | |
| | <p>[FINISHING RECOMMENDATION]</p> <p>*Pre-soaking is important. Before washing, soak the fabric in hot water to ensure it absorbs moisture thoroughly.</p> <p>*A washing treatment is crucial to finish the fabric. If the shrinkage and fullness are insufficient, adjust the spin dry duration to retain moisture in the fabric. With substantial moisture, a tumble dry will increase the distinguished fullness of Spugna.</p> | | |
| SPECIAL CARES: | 1. The cone should not be rewinded since not appropriate winding could jeopardize the yarn quality. 2. This yarn is dyed in hunks, and has the knots in composition, please knit with care to avoid the knots 3. The French wool used in this item is a valuable raw material which is usually used for carpets and materials. It is specially processed for knitting yarn. There is possibility to contain contaminates. This is a characteristic of raw materials and cannot be completely removed. It is necessary to make trials in your own knits before starting production. | | |
| CARE INSTRUCTION: |  | | |